

Manual

<u>for</u>

Controller NCD



For the operation of Turntables TT, Turn Device TD and Antenna Masts

Web:



<u>Index</u>

1)	General Ir	nstructions and Precautions	Page 3
2)	Technical	Data of Controller NCD	Page 4
3)	Commissi	oning	Page 6
4)	Menu Gui	dance	Page 7
5)	4.1) 4.2) 4.3) 4.4) 4.5) 4.6) 4.7) 4.8) 4.9) 4.10) 4.11) 4.12) 4.13) Trouble S	GPIB or LAN Logger Remote Address	Page 8 Page 10 Page 11 Page 12 Page 12 Page 13 Page 13 Page 14 Page 15 Page 15 Page 16 Page 16 Page 17
- Decla	idix anty Stater aration of C ote comma	Conformity	Page 20 Page 21 Page 22



1) General Instructions and Precautions

Before this device is applied with power:

Ground it properly through the protective conductor of the power cable to a power source provided with protective earth contact. Any interruption of the protective (grounding) conductor, inside or outside the device, or disconnection of the protective earth terminal could result in personal injury.

The electrical installation of this product must be accomplished by an individual who is authorized to so do by the appropriate local authority. The installation must be in compliance with local electrical safety codes.

Only qualified personnel are allowed to operate or service this equipment.

Before making service, contact maturo GmbH

Service or modifications of the device by yourself may void your warranty.

If you attempt to service the unit by yourself, disconnect all electrical power before starting. There are voltages at many points in the components which could, if contacted, cause personal injury. Only trained service personnel are allowed to perform adjustments and/or service procedures upon this device. Capacitors inside this instrument may still be charged even when instrument is disconnected from its power source.

Stay clear of moving components during the operation of the device. Do not operate the device while somebody is close to moving parts.

The protection of the **area of risk** at site is part of the operator.

Read this manual completely before starting installation. This equipment must be installed and operated only by qualified personnel.

Regularly inspect all equipment and conduct scheduled maintenance in accordance with the factory recommendations provided. Only use replacement parts and fasteners ordered directly from the factory.

Information presented enclosed is subject to change as product enhancements are made regularly. Every effort has been made to ensure that the information in this manual is accurate. However, no liability or guarantee is assumed for the up-to-dateness, correctness and completeness of the information provided herein.

Pictures included are for illustration purposes only and do not represent all possible configurations.



2) Technical Data of Controller NCD

The Multiple Control Device **NCD** is suited for the operation of up to 8 devices with multiple axis of motion. Those devices can be any combinations of antenna masts, turntables, cable guide rails or any other positioning equipment.

This controller NCD permits the operation in manual, semi-automatic and remote control mode via IEEE 488.2 (GPIB bus), or optionally other interfaces, of multiple devices simultaneously.



Figure: NCD with option "tip-up handle"

Technical Data

Data interfaces IEEE 488.2 (GPIB-Bus) and Ethernet

Transmission Fibre optic cable 1G50/125 (up to 2000 m distance)

Transfer rate 100 Mbit/s (fast Ethernet)

Display 5.7" TFT Touch screen-Display

Voltage 100-240 VAC, 47-63 Hz, single phase

Current consumption max. 70W Fuse 2x T 1.6A

Size (W X D) 19" Rack mount and table unit (427 x 300 mm)

Height 3 HE (133 mm)

Temperature range 5°C - 40°C

Total weight approx. 8 kg

Accessories 1.5 m power supply cable, Service manual

Phone: +49 (0)9606 923913-0 Fax: +49 (0)9606 923913-29 eMail: info@maturo-gmbh.de Web: www.maturo-gmbh.de



Brief description of NCD

The multiple control device NCD works with KeySight (former Agilent), R&S, Teseq and other software. The IEEE 488 (GPIB) is available as a standard interface device. Other interfaces available upon request.

Highlights:

- User-friendly, time-saving function keys optionally available

The function keys F1 to F10 allows the implementation of individual, customerspecific sequence programs for user-friendly, times-saving handling and operation. The individual programs can be stored and accessed by one function key.

- Error analysis based on error codes

Diagnosis via USB interface possible Optional analysis via internet and Ethernet interface possible

USB interface

Updates easily implemented by USB stick Possibility to plug in a computer mouse and keyboard

Easy operation with touch panel

Fast and reliable operability based on touch panel technology Layout of touch screen display can easily be adjusted according to customers' request

Position keys

With the position keys JOG+/JOG- the Positioners can easily be moved in manual mode.

- Real-time capable

Each program cycle will finished in the default time frame be no matter how many devices are controlled at the same time. Due to this feature no overflow of commands can happen when using fast remote computers.

- Handheld control unit

Easy implementation of standard or customer-specific handheld control units possible

Precise Display Accuracy

The display resolution is highly precise with position readout increments of 1 mm respectively 0.1 degree.

Higher resolutions possible upon request.

- Many additional options possible

Emergency stop buttons, handheld control units (HCU), luminaire, analogue outputs and much more additional features upon request




3) Commissioning Controller NCD

Bus Connection

The connection between the Controller NCD and the Positioner is performed by the included fibre optic cable.

Take care that the colours of cables match with the stickers at the backside of the controller and the drive units.



All Positioners will be activated automatically. If an additional device is connected, there is no need of a restart.

Power Supply

The power supply of all devices must be 110-240 VAC / 47-63Hz.

Switch On

Switch on black power switch of the Positioners.

Switch on black power switches at front and back of the controller.

Attention: The fibre optic cables of NCD are highly sensitive, ensure that it is not

bent too much or gets damaged any otherwise!

If cables or ports are not in use, the included dust protection covers must be used!

Even a minor, hardly visible dirtying of cable ends or feed-throughs (FSMA) harms the connection, up to complete communication

malfunction!

Therefore please have a look at Chapter 5) Troubleshooting.








4) Menu Guidance

Panel

The picture below shows the control panel



Switch On

The following picture appears after boot routine.




(Note: The picture above may not the original picture for your controller)

There is no need to connect your D1 Device to the first port. Each device can be connected to any free port of NCD.




4.1 Switch on Positioner



- By pressing "EN" key all Positioner will be activated and the LED light up green permanently.
- By pressing e.g. "D1/D5", each single device can be activated or deactivated. Whereas, at deactivating the button must be pressed for a longer period.
- To operate the devices D5 to D8, the button "D5-D8" must be pressed first. LED D5-D8 out: Device D1 to D4
- Press the relevant button for switching to the other Positioners.

LED D5-D8 on: Device D5 to D8

- In general, the devices are active where the LED light is on.







Note: The following brief descriptions are examples, but the controlling of most positioners is similar. Possibly your Device doesn't have all described functions.

By selecting a turntable the picture below appears. There is no need to reference the turntable. The displayed value of "Actual Angle" is indicated by an absolute encoder which is saving the last position, even after power off.

By pressing "To Settings" the adjustment possibilities for the device are shown.



By pressing key for Antenna Mast the picture below appears and the antenna mast is activated. Masts must be referenced before positioning is enabled. By pressing "To Settings" the adjustment possibilities for the device are shown.



Note: Yellow characters indicate the actual values.

At the bars which are indicated in white characters, input options are possible

Web:



4.2 Referencing

Before moving the antenna masts, they must be referenced.

Press "REF"-button after selecting a device in the user interface.

During the referencing, the LED of the "REF"-Button is blinking, after completion it lights permanently. This process must be done with every Mast device and after every restart of the NCD or of the device.

It is recommended to move masts to a low position before power off; otherwise the referencing can take a long time.



If you have a TAM or BAM device, the buttons "Tilt Up" and "Tilt Down" can be used to adjust the carriage considering to the bubble level. The angle is saved as 0° by pressing "Tilt Save" and the referencing of high starts automatically.

Other masts as AM or CAM will reference fully automatic by pressing the "REF"-button.


Referencing of TAM (or BAM)

If you have a TAM or BAM device, the buttons "Tilt Up" and "Tilt Down" can be used to adjust the carriage considering to the bubble level.

The angle is saved as 0° by pressing "Tilt Save" and the referencing of high starts automatically.

These three buttons are also at the side of the drive box of TAM or BAM.

Other masts as AM, CAM or DAM will reference fully automatic by pressing the "REF"-button.









Always make sure that the TAM is in bubble level before pressing "Save Tilt"
Serious damage can be the caused otherwise!!

4.3 Positioning

By pushing any "JOG" keys the Positioner moves in the respective direction. The movement stops either by releasing the "JOG" key or a limit is reached.

"JOG Min" means Down for Masts and CCW for Turntables.

"JOG Max" means Up for Masts and CW for Turntables.









By entering a "JOG-Distance", an incremental stepwise positioning is activated. The respectively axis moves by the indicated distance pressing the "JOG" key. This stepwise positioning can be repeated any number of times if no limit is reached. This function can be deactivated by entering "0.0" in the JOG- Distance menu.

The polarisation can be changed by pressing "To Hor" or "To Ver" keys.





Fax:



4.4 Actual and Target Position

The actual position is indicated in the respectively column "Actual Angle/High".

Any target position can be entered at "New Angle/High" and afterwards the positioning can be activated with the "START" key.

During the movement the positioning can be stopped with the "STOP" key and activated again with the "START" key.

Note: The "START" key is only valid for the selected device whereas the "STOP" key is valid for all devices.

New Angle : 100.0 °

Actual Angle : 100.0 °




4.5 Input of a Value

The input of any numerical value can be entered by either the Touch panel or the number pad.

By pressing "New Angle/High"-key the input is activated.

The following input field appears:






Any numerical value within the displayed minimum and maximum limits can be entered. The value is applied by pressing "OK" key.

The input can also be done by the number pad and applied with "Enter" key.



4.6 Settings




Speed and Acceleration/Deceleration

The speed and acceleration for both rotation axes can be changed by pushing the "Speed" or "Acc" keys at the Touch panel. Different speeds and accelerations can be entered within the indicated limits.

The indicated values are always used at operation directly from the NCD. At remote control via GPIB the values of speed and acceleration can be adjusted separately by the software.

Note: Acceleration/Deceleration cannot be set with GPIB

4.7 Settings for Tilt-Function and measurement distance at TAM



At this menu it is possible to activate or deactivate the tilt function and to set the measurement distance and EUT height.

EUT height:

- Before referencing balance the antenna with the levels.
- After referencing or if the EUT height was changed with key "EUT High", the new EUT height must first be confirmed by pressing the "Start" key and moving to the new height.
- The movement of the antenna mast is now possible again.


With these settings the required tilt angle depending on the distance is calculated automatically.




4.8 Error Diagnostics

If an error occurs, the diagnostics button in main screen of the device changes to red. To reset the error, press the diagnostics button first.

The error can be reset by pressing the button in the down left corner.



If an error appears regularly or always, you can get additional information to the error by pressing "NC1" – "NC4" Buttons. Each single motor of the device has its own NC menu. The screen below appears and provides more detailed information. This can be important for maturo to give a quick solution to your problem.



If you need support, please always note the serial number of your device and the error texts before contacting maturo.



4.9 GPIB or LAN settings




At this menu the speed with GPIB or LAN, the relevant limits and the device addresses are indicated.

If no other values are chosen, the default values are selected automatically.

4.10 Menu


By pressing the "MENU" key an overview of the system settings are shown.





4.11 GPIB or LAN Logger


The "GPIB Logger" or "LAN Logger" menu enables the analysis and interpretation of the received commands.



- "Init" key removes the entries in the table.
- By pressing the "Back" key, the system menu appears again.

4.12 Remote Address

Any Remote Address can be selected here.



- The current Remote Address is indicated.
- Change address by entering a new number and press "Set GPIB-Address"



It is possible to change to IP-address of the Controller. (Only with LAN interface)

- -Enter the new IP-address and subnetmask.
- -Press "Create Registry File"
- -Press "Update IP Address"
- -Press "Yes"
- -Press "Yes"

The Controller restarts automatically with the new IP-address.

4.13 PLC-Update

It is possible to update the Software of the Controller via the USB port. maturo can provide a boot project which needs to be copied to an USB stick.

By pressing "PLC-Update" the update will be copied and activated at the next restart of the controller.

For a safety update the actual Software from the controller can be saved on the USB Stick and can be restored if there are problems with the new Update.

By pressing "Save Current PLC" the Software from the controller will be copied to the USB Stick.

By pressing "Restore Saved PLC" the saved Software from the USB Stick will be copied to the controller.

More detailed instructions are given with every update.



5) Trouble Shooting Controller NCD

If there are problems with the controller, please always carry out the following first:

- 1. Check power supply must be between 100V and 240V
- 2. Check fuses at the backside of the controller
- 3. Check fuse at the Positioner
- 4. Check fibre optic cables and connections (if possible change cables from a different device and check)
- 5. Use a short cable for connection directly to the device in the chamber
- 6. Disconnect the power supply of the device and the controller. Reconnect the power supply and carry out referencing

Please contact our service department by:

Phone: +49 9606 9239130

Or by

Email: service@maturo-gmbh.de

When contacting maturo, please always provide the serial number of the products.



Trouble Shooting Controller NCD – cable cleaning

If you have connectivity malfunction, the cables or the feed-throughs (FSMA) may be dirty. Even if the cables never where disconnected, some dirt can get inside over time. The cables may even not look dirty and still the attenuation loss can be too high!

For best cleaning result, use the following tools:

At least 90% pure cleaning alcohol (other detergents can make it even worse!)

Compressed air spray can (optionally)


Small cotton sticks

Microfiber cloth



Use the microfiber cloth to clean all cable ends

Use the cotton sticks and compressed air to clean all feed-throughs (FSMA)





After cleaning, reconnect all cables and check connectivity again.

When not using cables or devices, always put on the provided dust covers!







Warranty Statement

Maturo GmbH, hereinafter referred as maturo, warrants that our standard products are free from defect in materials and workmanship for a period of one year from date of shipment, if maintenances are done regularly. Standard maturo products include the following:

- Antenna Mast and Stands
- Turntables and Turn Devices
- Cable guide rails
- Controllers
- Dynamometers for the automotive industry

If the Buyer notifies the Seller of a defect within the warranty period, the Seller will, at the Seller's option, either repair and/or replace those products that prove to be defective.

There will be no charge for warranty services performed at the location maturo designates. The customer must, however, prepay inbound shipping costs and any duties or taxes. Maturo will pay outbound shipping cost for a carrier of maturo's choice, exclusive of any duties or taxes. If maturo determines that warranty service can only be performed at the customer's location, the customer will not be charged for maturo's travel related costs.

This warranty does not apply for:

- Improper storage of our products outside our area of influence,
- Errors during installation, commissioning or operation,
- Wear and tear during normal operations,
- Unqualified maintenance works,
- The application of unsuitable equipment and materials,
- The results of repair works or other activities undertaken on our products, which have not been expressly approved by us.
- Consumable items such as fuses, batteries, etc.
- Products which have been operated outside the specifications

Note: Please always contact maturo before shipping equipment to us.



EG Konformitätserklärung gemäß EMV-Richtlinie 2004/108/EG

Declaration of Conformity in accordance with EMC guideline 2004/108/EC

Hiermit wird erklärt, dass das Produkt:

We hereby declare that the product:

Produktbezeichnung: Product:	Controller NCD	
Seriennummer: Serial number:	NCD/xxx/xxxxxxx	
Baujahr: Year:	2015	
Hersteller: Manufacturer:	maturo GmbH, Am Kalvarienberg 24, 92536 Pfreimd	

mit den Vorschriften folgender Europäischer Richtlinien übereinstimmt: has been manufactured according to the regulations of the following European directives:

- 2004/108/EG Elektromagnetische Verträglichkeit – EMV-Richtlinie

- 2004/108/EC Electromagnetic compatibility – EMC directive

- 2006/95/EG Niederspannungsrichtlinie
 - 2006/95/EC The Low Voltage Directive

Grundlagen dafür sind folgende harmonisierte Normen: *Basis for that are the following harmonized standards:*

- EN 55022:2010 Class B - EN 61000-4-2:2009 Level 2/3 - EN 61000-4-3:2006 + A1:2008 + A2:2010 Level 2 - EN 61000-4-4:2004 + A1:2010 Level 2

- EN 61010-1:2010 Safety requirements for electrical equipment for measurement, control and laboratory use.

maturo GmbH Am Kalvarienberg 24 92536 Pfreimd Info@maturo-9mbh.de Telefon: +49 (9606) 923913-0 Telefax: +49 (9606) 323913-29

Pfreimd, den 20.02.2013

Gerhard Strehl, Managing Director

Firmenstempel	Ort und Datum der Ausstellung	rechtsverbindliche Unterschrift
Company stamp	Place and date of issue	Name and signature of authorised person



Remote commands for the Controller NCD



For Antenna Mast AM and Stands AS Turntable TT &Turn Devices TD

Phone: +49 (0)9606 923913-0 Fax: +49 (0)9606 923913-29



<u>Index</u>

Chapter 1: Remote Commands for Antenna Masts and Stands	Page 24
Chapter 2: Remote Commands for Turntables & Turn Devices	Page 26
Chapter 3: Error Messages	Page 28
Chapter 4: General programming at NCD	Page 29
- Addressing to multiple devices	Page 29
- Speed setting	Page 29
- Go to new position	Page 29
- Readout of current position	Page 30



Chapter 1: Remote commands for Antenna Masts and Stands

General information

- All outputs through the Interface-Bus are five characters long, followed by Line Feed (0AH). Missing positions are filled with blanks (20H).
- All values are transferred in CM.
- Negative values are not allowed.
- The commands, values and units must be transferred in capital letters and separated by blanks.
- No more than 32 characters may be sent in one transmission.
- The Line Feed or the EOI can be used as an end character (CR will be ignored).

Registers

The Bus interface of the control device has several registers available. By transmitting the register name, the register is made the current register. If the device is addressed as TALKER, it outputs the contents of the register set.

If a value has been loaded previously with LD, it is accepted into the next following register.

Input Registers

These registers can be assigned a value with the LD command. They can be readout when the register name is received and the control unit is then addressed as TALKER.

UL - Upper Limit (General)

Cannot exceed the maximum height and must not be smaller than the minimum height.

UV - Upper Limit for vertical polarization

Cannot exceed the "Upper Limit".

LL - Lower Limit

Cannot exceed the minimum height and must not be larger than the maximum height.

NP - Next Position

Set point for the GO command.

Output Registers

These registers are only for readout of information.

CP - Current Position

BU - Busy Motor status

0: Motor is off 1: Motor is on

Phone: +49 (0)9606 923913-0 Fax: +49 (0)9606 923913-29 eMail: info@maturo-gmbh.de Web: www.maturo-gmbh.de



The BU register indicates if the motor and thereby also the mast is currently moving. For mechanical reasons, the motor cannot start immediately after the receipt of a start command.

Therefore it is necessary to wait until the mast moves (BU = 1), before it is possible to enquire with BU whether the previous command has been completed. If the mast is already located in the desired position when a GO command is received, BU will nevertheless be set on 1 for approx. 0.5 sec.

Commands to Load the Registers

LD nnn CM - Load the value nnn into the register following.

Commands to Control the Mast

UP - Moves the mast basket up until the upper limit is reached or a STOP command (ST) is received.

DN - Moves the mast basket down until the lower limit is reached or a STOP command (ST) is received.

GO - Moves the mast basket to the position, which is in the set point register (NP).

P? - Current polarization of the antenna.

0: Horizontal polarisation1: Vertical polarisation

PV - Sets the antenna to vertical polarization.

PH - Sets the antenna to horizontal polarization.

Commands to Control the AS

P? - Current polarization of the antenna.

0: Horizontal polarisation1: Vertical polarisation

PV - Sets the antenna to vertical polarization.

PH - Sets the antenna to horizontal polarization.



Chapter 2: Remote commands for Turntables & Turn Devices

General information

- All outputs through the Interface-Bus are five characters long, followed by Line Feed (0AH). Missing positions are filled with blanks (20H).
- All values are transferred in DG.
- The commands, values and units must be transferred in capital letters and separated by blanks.
- No more than 32 characters may be sent in one transmission.
- The Line Feed or the EOI can be used as an end character (CR will be ignored).

Registers

The Bus interface of the control device has several registers available. By transmitting the register name, the register is made the current register. If the device is addressed as TALKER, it outputs the contents of the register set.

If a value has been loaded previously with LD, it is accepted into the next following register.

Input Registers

These registers can be assigned a value with the LD command. They can be readout when the register name is received and the control unit is then addressed as TALKER.

WL - Wise Limit cannot be larger than 400°.

CL - Counter-clockwise Limit cannot be smaller than -200°.

NP - Next Position. Set point for the GO command.

SP - Speed, valid numbers are 1 to 8.

Output Registers

These registers are only for readout of information.

CP - Current Position

BU - Busy Motor status

0: Motor is off 1: Motor is on



The BU register indicates if the motor and thereby also the turntable or turn device are currently moving.

For mechanical reasons, the motor cannot start immediately after the receipt of a start command.

Therefore it is necessary to wait until the turntable moves (BU = 1), before it is possible to enquire with BU whether the previous command has been completed. If the mast is already located in the desired position when a GO command is received, BU will nevertheless be set on 1 for approx. 0.5 sec.

Commands to Load the Registers

LD nnn DG - Load the value nnn into the register following.

Commands to Control the Turntable or Turn Device

- CW Moves the table clockwise until the limit is reached or a STOP command (ST) is send.
- CC Moves the turntable or turn device counter-clockwise until the limit is reached or a STOP command (ST) is send.
- GO Moves the turntable or turn device to the position which is in the set point register (NP).
- ST Stops the movement of the turntable or turn device.



Chapter 3: Error Messages

exist.

E - P Power is sent after a loss of mains power
 E - S Syntax is sent when an invalid command is received
 E - V Value is sent when a value does not lie within the valid limits
 E - D Device is sent when the device no longer reacts, meaning that the motor does not move in spite of the control. It is also sent if the addressed device does not



Chapter 4: General programming at NCD

Addressing the several devices

If several devices are connected to the NCD, the controllable device needs to be addressed.

For example (One Antenna Mast and one Turntable)

"LD 0 DV" for the Antenna Mast for the Turntable.

This applies for setting a new position and for readout of the actual position of a device!

Speed setting of a device

You can set speed 1 to 8 with the SP-Register. To change the speed of the turntable, make the following two steps:

Select the Turntable "LD 1 DV"

Write "LD 5 SP" sets the speed to five. The speed depends on the maximum speed of the device.

For example the maximum speed of the turntable is 2.0 U/min $(2.0 \div 8) * 5 = 1.25$ U/min is the new speed

The maximum speed of each device can be readout in the device-menu of the NCD.

Note: The polarisation speed of the antenna mast cannot be change!

Go to a new position

For setting a new position of the turntable make the following two steps:

Select the Turntable "LD 1 DV"

Write the command "LD 180.0 DG NP GO" (the turntable moves to 180 degree)

With the commands "CC" and "CW" it is possible to move the turntable to minimum and maximum limit.

"CC" – Turntable moves to minimum limit (e.g.: -200 degree)

"CW" – Turntable moves to maximum limit (e.g.: +400 degree)

For stopping the turntable make the following two steps:

Select the turntable "LD 1 DV"

Write the command "ST"

For setting a new position of the antenna mast follow the same steps:

Except: Select the antenna mast with writing "LD 0 DV"

Write the command "LD 300.0 CM NP GO" (the antenna mast moves to 3.0 meter)

For polarization of the antenna mast write "PV" and "PH".



Readout the actual position of the device:

Select the device by writing "LD x DV". $(x = 0 \Rightarrow Antenna Mast and x = 1 \Rightarrow Turntable)$ Write "CP" (set the Pointer to the CP-Register) Readout of six Bytes (applies to antenna mast and turntable)

For polarization readout select the antenna mast Write "P?" and readout the position

In general all registers can be readout in the same way.

E.g.: WL and the CL Register

Device address	Device
0	Antenna Mast 1
1	Turntable 1 (TT)
2	Cable Guide Rail (CGR) or Field Probe Positioner (FPP)
3	Turn Device (TD)
4	(Compact) Antenna Mast 2 or Antenna Stand
5	Turntable 2 (TT)

maturo GmbH Am Kalvarienberg 24 。 92536 Pfreimd 。 Germany Web: www.maturo-gmbh.de	maturo
	Notes
	maturo Gml